



User Manual



Thank you for purchasing Kaprow's 842 Prolaser® Bambino. You now own one of the most advanced laser tools available. This manual will show you how to get the most out of your laser tool.

APPLICATIONS

The 842 Prolaser® Bambino is a laser level with one red diode. The laser is innovatively designed for a very broad range of professional and DIY jobs, including:

- Aligning tiles, marble, cabinets, borders, moldings and trimmings
- Marking lay out for doors, windows, rails, stairs, fences gates, decks and pergolas installation.
- All types of DIY jobs, including hanging shelves, hanging hooks, pictures, curtains and more

NOTE

Keep this user manual for future reference.

SAFETY INSTRUCTIONS

WARNING

This product is emitting radiation that is classified As class II according to EN 60825 -1

The laser radiation can cause serious eye injury

- Do not stare into the laser beam
- Do not position the laser beam so that it unintentionally blinds you or others.
- Do not operate the laser level near children or let children operate the laser level.
- Do not look into a laser beam using magnifying optical devices such as binoculars or a telescope, as this will increase the level of eye injury.


WARNING: This product contains lead in solder and certain Electrical parts contain chemicals which are known to the State of California to cause cancer, birth defects or other Reproductive harm.
(California Health & Safety Code Section 25249.6- Proposition 65)

NOTE

The red goggles are intended to enhance the visibility of the laser beam. They will not protect your eyes against laser radiation.

OVERVIEW

1. On/Off Locking Switch
2. Laser output window
3. Manual Mode button
4. Operation LED indicator
5. Battery cover
6. ¼" Tripod mount



CONTENTS

• Features	3
• Safety instructions	4-5
• Battery installation & Safety	6
• Overview	7
• Operating instructions	8-9
• Maintenance	10
• Field calibration test	11-16
• Specifications	17
• Warranty	18

FEATURES


- This laser tool automatically determines the horizontal and vertical plans.
- The laser projects intersected horizontal and vertical lines.
- Max. indoor working range - 15 m (50').
- Self-levels in automatic mode when the laser is positioned within its self-leveling range.
- Visual warning (blinking) when the laser is out of leveling range falls.
- Manual mode allows angular layout/markings.
- Locking mechanism to protect the pendulum during transportation.
- 1/4" tripod adaptor.
- Compact size - fits in your toolbox.

NOTE

This device contains precision components that are sensitive to external shock, impact or drop that may compromise its functionality –handle with care to maintain its accuracy.

BATTERY INSTALLATION & SAFETY

1. Push the latch and open the battery cover.
2. Insert 2 new AA batteries of the same brand according to the polarity diagram on the inside of the battery compartment.
3. Close the battery cover.



NOTE

If the laser level will not be used for a long period of time, remove the batteries from the battery compartment. This will battery leakage and corrosion damage.

WARNING: Batteries can deteriorate, leak or explode, and can cause injury or fire.


1. Do not shorten the battery terminals.
2. Do not charge Alkaline batteries.
3. Do not mix old and new batteries.
4. Do not through batteries into household waste.
5. Do not dispose of the batteries in fire.
6. Defective or dead batteries must be disposed of according to local regulations.
7. Keep the batteries out of reach from children.

OPERATING INSTRUCTIONS

Working in Automatic Mode (self-leveling):

In automatic mode the laser level will level itself in the range of ±3° and will project crossed horizontal and vertical laser beams.

1. Remove the laser from the pouch and place it on a solid, flat, vibration free surface or on a tripod
2. Push the locking switch #1 to the position.
The laser level will generate the crossed horizontal and vertical lines and the green LED will light up.
3. If the initial slope of the laser is beyond ±3° the laser lines will flash. In this case reposition the laser on a more leveled surface.
4. Before moving the laser level switch the locking switch #1 back to the position, this will lock the pendulum and protect your laser.



Working in Manual Mode:

In manual mode the self-leveling mechanism of the 842 is disabled (button #1 is in OFF position) and the laser lines can be set at any slope required.

1. To activate the Manual mode, long press the #3 button.
The laser will project blinking cross lines and the red LED will light up.
2. Tilt the laser to the desired slope.
3. To turn the manual mode off, press the Manual mode button again.
4. While in Manual mode turning the locking switch #1 from to position will turn off the Manual mode. The automatic self – leveling will be activated if the laser level is within the self – leveling range.

MAINTENANCE

- To maintain the accuracy of your project, check the accuracy of your laser level according to the field calibration tests procedures.
- Change the batteries when the laser beams begin to dim.
- Wipe the aperture lens and the body of the laser level with a clean soft cloth. Do not use solvents.
- Although the laser level is dust and dirt resistant to a certain degree, do not store in dusty places as long term exposure may damage internal moving parts.
- If the laser level is exposed to water, dry the laser level before returning it to the carrying case to prevent corrosion damages.
- Remove the batteries if the laser level is unused for an extended period, to prevent corrosion damage.

10

FIELD CALIBRATION TEST

This laser level left the factory fully calibrated. Kapro recommends checking the accuracy of the laser periodically, or if the unit falls or is mishandled.

To do so, first check the height accuracy of the horizontal line, then check the leveling accuracy of the horizontal line, and finally check the leveling accuracy of the vertical line.

Checking the Height Accuracy of the Horizontal Line. (Up and down deviation)

- Set up the laser on a tripod or on a flat surface between two walls **A** and **B**, approximately 5 meters apart.
- Position the laser level approximately 0.5 meter from wall **A**
- Unlock the pendulum and press the button to project the horizontal and the vertical cross lines towards wall **A**.
- Mark the center of the cross lines as **a1** on the wall. (see figure 1)




Figure # 1

11

- Turn the laser 180° towards wall **B**, and mark the center of the cross lines as **b1** on the wall (see figure 2).




Figure # 2

- Move the laser level towards wall **B** and position it approximately 0.5 meters from wall **B**.
- On wall **B** mark the center of the cross lines as **b2** (see figure 3).




Figure # 3

12

- Turn the laser 180° towards wall **A**, and mark the center of the cross lines as **a2** on the wall (see figure 4).




Figure # 4

- Measure the distances:

$$\Delta a = |a2 - a1|$$

$$\Delta b = |b1 - b2|$$

- The difference $|\Delta a - \Delta b|$ should be no more than 4 mm, otherwise send the laser level to a qualified technician for repair.

Checking the Level Accuracy of the Horizontal Line. (Side to side inclination)

- Set up the laser on a tripod or on a flat surface at a distance of approximately 1.5 meters from a 5 meter long wall.
- Unlock the pendulum and press the button to project the horizontal and the vertical cross lines towards the wall.

13

- Mark point **a1** on the wall, in the middle of the horizontal line at the left edge of the horizontal line (see figure 5).




Figure # 5

- Turn the laser level counterclockwise until the right edge of the horizontal line reaches near **a1**, mark a point **a2** on the wall, in the middle of the horizontal line (see figure 6).




Figure # 6

14

- The distance between **a1** and **a2**, should be no more than 2 mm otherwise send the laser level to a qualified technician for repair.

Checking the Accuracy of the Vertical line.

- Hang an approximately 4 meter plumb line on a wall.
- After the plumb line has settled, mark point **a1** on the wall, behind the plumb line near the plumb cone. (see figure 7).




Figure # 7

- Set up the laser on a tripod or on a flat surface in front of the wall, at a distance of approximately 2 meters.
- Unlock the pendulum and press the button to project the vertical line toward the plumb line.
- Turn the laser so that the vertical line will merge with the plumb line below the hanging point.

15

- Mark point **a2** on the wall, in the middle of the vertical line at the same height as **a1**. (see figure 8).




Figure # 8

- The distance between **a1** and **a2**, should be no more than 2 mm, otherwise send the laser level to a qualified technician for repair.

16

SPECIFICATIONS

Laser beams output pattern	Vertical and horizontal cross lines
Laser range	Indoor - 15m (50ft)
Accuracy	±0.4mm/m (±0.0004in/in)
Fan angle	100° ±5°
Self-leveling range	±3°
Laser line width	2.5 mm±0.5mm/5m (0.13" ±0.02" at 20')
Wavelength	635 ±5nm - Laser Class II
Power supply	2 AA batteries (included)
Battery life	25 hours of continuous operation
Operating temp.	-10° C + 45° C (14°F +113°F)
Storage temp.	-20° C +60° C (-4°F +140°F)
Water & dust proof	IP54
Dimensions	7.6cm x 6.5cm x5cm (3" x 2.6" x 2")
Weight including batteries	180gr±10gr (0.4 lbs±0.35 oz)

17

WARRANTY

This product is covered by a two-year limited warranty against defects in materials and workmanship. The warranty does not cover products that are used improperly, altered or repaired without Kapro Tool's approval. In the event of a problem with the laser level, please return the product to the place of purchase with proof of purchase.

Model #842 Prolaser Bambino.

The Serial number sticker is positioned on the battery compartment.

CE CONFORMITY CERTIFICATE

This product meets the standards of the Electromagnetic Compatibility (EMC) established by the European Directive 2014/30/EU and the Low Voltage Directive (LVD) 2014/35/EU

EC DECLARATION OF CONFORMITY

We declare under our responsibility that the product 842 is in accordance with the requirements of the Community Directives and Regulations:

2014/30/EU
2011/65/EU
EN60825-1: 2014
EN61326-1: 2013

18